



STARLITE[®] COMBO



FRONT PANEL CONTROLS



INPUTS

Input 1 : High Sensitivity
Use this input for max pickup output and frequency response.
Input 2 : Low Sensitivity (6dB)
Use this input for hotter pickups / lower gain.

VOLUME

Controls overall gain/volume. Typically, breakup will begin to occur around 5-6 on the dial.

STONE

Covers both Black panel and Tweed era amps with a unique designed mid-cut below 12 O'clock.

FEEDBACK SWITCH

Activates the negative feedback loop. Reduces overall power amp gain and will alter the "feel" of the amplifier.

REMOTE SPEAKER

External 8 Ohm speakers connect here. Note that internal speaker is disengaged when remote is activated.

STANDBY SWITCH

Allow the amplifier 1 minute to warm up before engaging. Use the standby switch during short breaks to increase tube life.

POWER SWITCH

Turns the amplifier on and off.
Make sure you are plugged into a proper grounded outlet.

FUSE

Always replace with same type and rating.
100-120V - 50/60HZ T1AL 250V
220-240V - 50/60HZ T1/2AL 250V